

Instructions For Safe Use of LadderAnchor

1. Read and obey all warnings and safety instructions before each use.
2. Ensure user is adequately trained in the safe operation of ladders.
3. Read installation instructions and ensure LadderAnchor is properly secured to ladder before each use.
4. Check all equipment for defects or damage (*e.g.*, loose bolts, cracked plastic, broken cleats, damaged rubber, etc.) before each use. Do not use if you observe a defect or damage on equipment.
5. Only use LadderAnchor on stable, level surface where LadderAnchor is firmly secured to the ground. Do not place LadderAnchor on ice, gravel, wood chips, under water, or on loose or uneven ground.
6. Select either the “cleat” or “non slip rubber” side of the LadderAnchor based on your ground surface. For soft surfaces that will allow penetration, use the cleat side. For hard surfaces, use the non slip rubber side.
7. Make sure the retaining pins are fully engaged through rotating mounts.
8. Follow OSHA and ladder manufacturer’s standards for safe ladder use and climbing practices
9. Always use three points of contact while climbing the ladder and always work facing the ladder.
10. Always wear proper slip resistant shoes when climbing ladder.
11. Never move, extend, or shift a ladder with user standing on it.
12. Do not reach out too far in any direction while standing on the ladder. Always keep your belt buckle (belly button) centered with ladder and be sure not to over reach.
13. Do not use LadderAnchor near power lines or in inclement weather.
14. Do not transport ladder with a LadderAnchor attached.

For more information visit LadderAnchors.com.